

## Sewing Machine Comparison Guide



Sewing Machine Model	Store (S), Online (O) Both (B)	Number of Built in Stitches	NoError Threading™ Process	Makes Buttonholes	Top Drop-in Bobbin	Surefit™ Bobbin System	Number of Lights	Programmable Needle Up/Down	Maximum Stitch Width
Singer® 2932 (limited quantity)	S	35		Fully Automatic					6mm
Singer® 4205 Inspiration™	S	5	√	Automatic - Four Step	√	√	1 LED light		6mm
Singer® 4206 Inspiration™	B	6	√	Fully Automatic	√	√	1 LED light		6mm
Singer® 4210 Inspiration™	S	10	√	Automatic - Four Step	√	√	1 LED light		6mm
Singer® 4212 Inspiration™	B	12	√	Fully Automatic	√	√	1 LED light		6mm
Singer® 7462 Touch & Sew™	B	30		2 Styles of Fully Automatic	√		1 LED light		7mm
Singer® 7466 Touch & Sew™	B	70		3 Styles of Fully Automatic	√		1 LED light		7mm
Singer® Touch & Sew 7468	O	93		One-step Buttonhole (multi style)	√		1 LED light	√	7mm
Singer® 7430 CB5	O	144		One-step Buttonhole (multi style)	√		1 LED light		7mm
Singer® 7470 Confidence™	B	173		7 Styles of Fully Automatic	√		2 LED lights	√	7mm
Singer® CE-150 Futura™ (Embroidery Capable)	S	24		2 Styles of Fully Automatic	√		3 LED lights	√	7mm
Singer® CE-250 Futura™ (Embroidery Capable)	S	100		7 Styles of Fully Automatic	√		3 LED lights	√	7mm
Brother ES2000	O	40		One-step Buttonhole (multi style)	√		Dual LED		7mm
Brother CS6000i Computerized Sewing Machine	O	60		One-step Buttonhole (multi style)	√		Dual LED		7mm
Brother XL 2610	O	25		Four Step	√		1 light		5mm
Brother XL3750	O	35		One-step Buttonhole (multi style)	√		1 light		5mm
Brother PE-700 Embroidery Machine	O	Embroidery only			√		1 light	√	n/a
Brother SE270D Embroidery Machine	O	67		One-step Buttonhole (multi style)	√		Dual LED	√	7mm
Juki TL-98Q	O	1 (straight stitch)		No (no built-in pattern)			1 light		Straight stitch only
Juki TL-98QE	O	1 (straight stitch)		No (no built-in pattern)			1 light		Straight stitch only
White 1730 Quilt'N Sew	S	17		Automatic - Four Step	√		1 light		6mm
White D'Lite 1750	S	66		5 Styles of Fully Automatic	√		1 light	√	7mm

Sergers	Store (S), Online (O) Both (B)	Stitches per Min	Free Arm	Lay-in Threading/Tension	Thread Capacity	Differential Feed	Flatlock/Coverhem	Extra-High Presser Foot Lift
Singer® 14t967DC Quantumlock	B	1300		Lay-in Threading with Automatic Tension	2/3/4/5 Thread Capacity	√	2 or 3 Needle Coverhem and Flatlock	
Singer® 14CG754 Commercial Grade Serger	B	1300	√	Lay-in Color Coded Threading and One-turn Numbered Tension Dials	2/3/4 Thread Capacity	√	Flatlock Stitch	√
Brother 1034D	O	1300	√	Lay-in Threading	3/4 Thread Capacity	√	Flatlock Stitch	

## Sewing Machine Comparison Guide (continued)



Sewing Machine Model	Drop Feed	Twin Needle Capability	Free Arm	Needle Positions	Automatic Needle Threader	Snap - On Presser Feet that come with the Machine
Singer® 2932 (limited quantity)	√	√	√	2	√	Zipper, Buttonhole, Button Sewing and General Purpose Foot
Singer® 4205 Inspiration™	Cover Plate	√	√	Multiple		General Purpose, Buttonhole, Special Purpose, Zipper, Blind Hem Bonus - Darning and Embroidery, Gathering Foot
Singer® 4206 Inspiration™	Cover Plate	√	√	Multiple	√	General Purpose, Buttonhole, Special Purpose, Zipper, Blind Hem Bonus - Darning and Embroidery, Gathering, Rolled Hem and 1/4" Foot
Singer® 4210 Inspiration™	Cover Plate	√	√	Multiple	√	General Purpose, Buttonhole, Special Purpose, Zipper, Blind Hem Bonus - Darning and Embroidery, Gathering, Rolled Hem and 1/4" Foot
Singer® 4212 Inspiration™	Cover Plate	√	√	Multiple	√	General Purpose, Buttonhole, Special Purpose, Zipper, Blind Hem Bonus - Darning and Embroidery, Gathering, Rolled Hem, 1/4" Walking Foot
Singer® 7462 Touch & Sew™	Cover Plate	√	√	13	√	General Purpose, Satin Stitch, One-step Buttonhole, Zipper, Blind Hem
Singer® 7466 Touch & Sew™	√	√	√	13	√	General Purpose, One-step Buttonhole, Satin, Zipper, Blind Hem
Singer® Touch & Sew 7468	√	√	√	13	√	General Purpose, One-step Buttonhole, Satin, Zipper, Blind Hem
Singer® 7430 CB5	√	√	√	13	√	General Purpose, One-step Buttonhole, Satin, Zipper, Blind Hem
Singer® 7470 Confidence™	√	√	√	13	√	General Purpose, One-step Buttonhole (With Underplate), Special Purpose, Zipper, Blind Hem
Singer® CE-150 Futura™ (Embroidery Capable)	√	√	√	13	√	General Purpose, One-step Buttonhole, Zipper, Blind Hem, Embroidery Foot and 2 Hoops 4.5" x 6.75" and 3.125" x 4.75"
Singer® CE-250 Futura™ (Embroidery Capable)	√	√	√	13	√	General Purpose, One-step Buttonhole, Satin, Button, Zipper, Blind Hem, Embroidery Foot and 2 Hoops 4.5" x 6.75" and 3.125" x 4.75"
Brother ES2000	√	√	√	variable	√	Straight-ZigZag, Buttonhole, Zipper, Button Sewing, Blind Stitch, Overcasting, Monogramming
Brother CS6000i Computerized Sewing Machine	√	√	√	variable	√	Straight-ZigZag, Buttonhole, Overcasting, Monogramming, Zipper, Blind Stitch, Button Fitting, Walking foot with Quilt guide
Brother XL 2610	√	√	√	variable	√	Straight-ZigZag, Buttonhole, Zipper, Button Sewing, Rolled Hem, Blind Stitch Foot
Brother XL3750	√	√	√	variable	√	Straight-ZigZag, Buttonhole, Zipper, Button Sewing, Narrow Hemmer, Blind Stitch, Spring Action Quilting, Walking Foot with Quilt Guide
Brother PE-700 Embroidery Machine	√		√		√	Embroidery Foot
Brother SE270D Embroidery Machine	√	√	√	variable	√	Straight-ZigZag, Buttonhole, Zipper, Button Sewing, Blind Stitch, Overcasting, Monogramming-Embroidery Foot
Juki TL-98Q	√			1	√	Hemming, Zipper Attachment, Even Feed, 1/5" Quilting, 1/4" Quilting and 1/4" Straight Stitch Foot with Guide
Juki TL-98QE	√			1		Even Feed, 1/4" Quilting and 1/4" Straight Stitch Foot with Guide
White 1730 Quilt'N Sew	√	√	√	3	√	All purpose, Buttonhole, Zipper, Piecing Foot, Cover Plate and Twin needle
White D'Lite 1750	√	√	√		√	All purpose, Buttonhole, Zipper, Satin, Overcasting and Blind Hem Foot